


ROZTEČ VRTÁNÍ C (mm)	DĚLKA L (mm)	ŠÍŘKA D (mm)	VÝŠKA H (mm)	CHROM
KNOPKA	17	17	24	US011
32	48	21	26	US008
96	114	21	30	US007
128	145	21	30	US006



ROZTEČ VRTÁNÍ C (mm)	DĚLKA L (mm)	ŠÍŘKA D (mm)	VÝŠKA H (mm)	CHROM
32	50	50	26	US010
64	86	86	28	US009

